

Link do produktu: <https://sklep-agrotur.pl/nakretka-kola-3009748x1-p-17666.html>

NAKRĘTKA KOŁA 3009748X1

Cena	36,00 zł
Dostępność	Dostępny
Czas wysyłki	24 godziny
Numer katalogowy	6041
Kod producenta	3009748X1
Producent	ARGO TRACTORS

Opis produktu

NAKRĘTKA KOŁA 3009748X1

McCormick

- - CL
- - CX-L
- - C-Max/ C-Max RPS
- - F Top/ F E-Line/ F XL
- - G-Max// G-Max E
- - GM
- - MC
- - T-Max
- - V/ F-N
- - X4
- - X5
- - X50
- - X6
- - X6 LWB
- - X60
- - X70
- - X7.6

Landini

- - Alpine
- - Ghibli

- - Globalfarm
- - Globus
- - Landpower/ Landpower T-Tronic
- - Legend
- - Mistral
- - Mythos
- - Powerfarm/ Powerfarm RPS
- - Powermaster
- - Powermondial
- - Rex Top/ Rex Techno
- - Rex V/S
- - Seria 4 T4
- - Seria 5 D T4
- - Seria 5 H
- - Seria 5 H T4
- - Seria 6 T4
- - Seria 6 C
- - Seria 6 L
- - Seria 7
- - Seria 7 T4
- - Technofarm
- - Vision

Massey Ferguson

- - MF 1007 TRACTOR
- - MF 1014 TRACTOR
- - MF 1024 TRACTOR
- - MF 1114 TRACTOR
- - MF 1134 TRACTOR
- - MF 2210 COMPACT TRACTOR
- - MF 2220 COMPACT TRACTOR
- - MF 2225 COMPACT TRACTOR
- - MF 2230 COMPACT TRACTOR
- - MF 2235 COMPACT TRACTOR
- - MF 240 TRACTOR - INDIA

- - MF 230 TRACTOR
- - MF 240 TRACTOR, |-> A20287
- - MF 243 TRACTOR
- - MF 253/263 TRACTOR
- - MF 275/375 E TRACTOR, |-> P12018
- - MF 290/390 E TRACTOR, |-> P06156
- - MF 375 E TRACTOR, |-> P12018
- - MF 390 E TRACTOR, |-> P06156
- - MF 334 V TRACTOR
- - MF 354 AQ CAB TRACTOR
- - MF 354 F TRACTOR
- - MF 354 FQ CAB TRACTOR
- - MF 354 S TRACTOR
- - MF 354 SP - FP - AP - GE TRACTOR
- - MF 354 SQ CAB TRACTOR
- - MF 354 V FOOTSTEP TRACTOR
- - MF 354 V TRACTOR, ->| 30/06/94
- - MF 354 VQ TRACTOR, CAB, |-> 01/07/94
- - MF 354/3210 SP(X)-FP(X)-GE(X) FOOTSTEP TRACTOR
- - MF 362 N TRACTOR
- - MF 363 LX TRACTOR
- - MF 363 S TRACTOR
- - MF 363 TRACTOR
- - MF 364 AQ CAB TRACTOR
- - MF 364 F TRACTOR
- - MF 364 FQ CAB TRACTOR
- - MF 364 S TRACTOR
- - MF 364 SP - FP - AP - GE TRACTOR
- - MF 364 SQ CAB TRACTOR
- - MF 364 V FOOTSTEP TRACTOR
- - MF 364 V TRACTOR, ->| 30/06/94
- - MF 364 VQ TRACTOR, CAB, |-> 01/07/94
- - MF 373 LX TRACTOR
- - MF 373 S TRACTOR
- - MF 373 TRACTOR

- - MF 374 AQ CAB TRACTOR
- - MF 374 F - H TRACTOR, ->| 30/09/93
- - MF 374 FQ CAB TRACTOR, |-> 01/10/932
- - MF 374 S TRACTOR, ->| 30/09/93
- - MF 374 SP - FP - AP - GE TRACTOR
- - MF 374 SQ CAB TRACTOR, |-> 01/10/93
- - MF 374 V FOOTSTEP TRACTOR
- - MF 374 V TRACTOR, ->| 09/93
- - MF 374 VQ CAB TRACTOR, |-> 02/95
- - MF 374/3220 SP(X)-FP(X)-AP(X)-GE(X) FOOTSTEP TRACTOR
- - MF 377 TRACTOR
- - MF 382 N TRACTOR
- - MF 384 AQ CAB TRACTOR
- - MF 384 F TRACTOR, ->| 08/94
- - MF 384 FQ CAB TRACTOR, |-> 01/10/93
- - MF 384 S TRACTOR, ->| 30/09/93
- - MF 384 SP - FP - AP - GE TRACTOR
- - MF 384 SQ CAB TRACTOR, |-> 01/10/93
- - MF 384 V FOOTSTEP TRACTOR
- - MF 384 VQ TRACTOR, CAB, |->
- - MF 384/3225 SP(X)-FP(X)-AP(X)-GE(X) FOOTSTEP TRACTOR
- - MF 387 TRACTOR
- - MF 394 AQ CAB TRACTOR
- - MF 394 F - H TRACTOR, ->| 08/94
- - MF 394 FQ CAB TRACTOR, |-> 01/10/93
- - MF 394 H TRACTOR
- - MF 394 S TRACTOR, ->| 30/09/93
- - MF 394 SP - FP - AP - GE TRACTOR
- - MF 394 SQ CAB TRACTOR, |-> 01/10/93
- - MF 394 T AQ TRACTOR CAB
- - MF 394/3235 SP(X)-FP(X)-AP(X)-GE(X) FOOTSTEP TRACTOR
- - MF 396 TRACTOR
- - MF 397 T TRACTOR
- - MF 397 TRACTOR
- - MF 4225/4235/4240 TRACTOR | => K37009

- - MF 4245/4255 TRACTOR | => K37009
- - MF 4260/4270 TRACTOR | => K37009
- - MF 4265/4365 TRACTOR
- - MF 4315/4320 TRACTOR
- - MF 4325/4335 TRACTOR
- - MF 4345/4355 TRACTOR
- - MF 4360/4370 TRACTOR
- - MF 5410 TRACTOR (TIER 3)
- - MF 5420 TRACTOR (TIER 3)
- - MF 5425 TRACTOR (TIER 3)
- - MF 5425 / 5435 TRACTORS - --->| T163022 / --->| T186043
- - MF 5430 TRACTOR (TIER 3)
- - MF 5435 TRACTOR (TIER 3)
- - MF 5440 TRACTOR (TIER 3)
- - MF 5445 TRACTOR (TIER 3)
- - MF 5445 / 5455 TRACTORS - --->| T190042 / --->| T190045
- - MF 5450 TRACTOR (TIER 3)
- - MF 5455 TRACTOR (TIER 3)
- - MF 5460 TRACTOR (TIER 3)
- - MF 5460 TRACTOR (TIER 3 Sisu Engine)
- - MF 5460 / 5460 SA TRACTORS
- - MF 5465 TRACTOR
- - MF 5465 TRACTOR (TIER 3 / Perkins Engine)
- - MF 5465 TRACTOR (TIER 3 Sisu Engine)
- - MF 5470 TRACTOR
- - MF 5470 TRACTOR (TIER 3)
- - MF 5470 SA / 5475 SA TRACTORS
- - MF 5475 TRACTOR (TIER 3 / Perkins Engine)
- - MF 5475 TRACTOR (TIER 3 Sisu Engine)
- - MF 5480 TRACTOR (TIER 3)
- - MF 5608 TRACTOR
- - MF 5609 TRACTOR
- - MF 5610 TRACTOR
- - MF 6150 TRACTOR
- - MF 6160 TRACTOR

- - MF 6170 TRACTOR
- - MF 6180 TRACTOR
- - MF 6190 TRACTOR
- - MF 6445 TRACTOR (TIER 3)
- - MF 6445/6455 TRACTOR
- - MF 6455 TRACTOR (TIER 3)
- - MF 6460 TRACTOR (TIER 3)
- - MF 6460/6470 TRACTOR
- - MF 6465 TRACTOR (TIER 3 / Perkins Engine)
- - MF 6465 TRACTOR (TIER 3 Sisu Engine)
- - MF 6465/6475/6480 TRACTOR
- - MF 6470 TRACTOR (TIER 3)
- - MF 6475 TRACTOR (TIER 3 / Perkins Engine)
- - MF 6475 TRACTOR (TIER 3 Sisu Engine)
- - MF 6480 TRACTOR (TIER 3 / Perkins Engine)
- - MF 6480 TRACTOR (TIER 3 Sisu Engine)
- - MF 6485 TRACTOR (DYNA 6 / TIER 3)
- - MF 6485 / 6490 TRACTORS
- - MF 6490 TRACTOR (DYNA 6 / TIER 3)
- - MF 6495 TRACTOR
- - MF 6495 TRACTOR (DYNA 6 / TIER 3)
- - MF 6497/6499 TRACTOR
- - MF 6612 TRACTOR (DYNA 4)
- - MF 6613 TRACTOR (DYNA 4)
- - MF 6613 TRACTOR (DYNA 6)
- - MF 6614 TRACTOR (DYNA 6)
- - MF 6614 TRACTOR (DYNA VT / DYNA STEP)
- - MF 6615 TRACTOR (DYNA 4)
- - MF 6615 TRACTOR (DYNA 6)
- - MF 6615 TRACTOR (DYNA VT / DYNA STEP)
- - MF 6616 TRACTOR (DYNA 6)
- - MF 6616 TRACTOR (DYNA VT / DYNA STEP)
- - MF 7465 TRACTOR (TIER 3 Sisu Engine)
- - MF 7465 TRACTOR (TIER 3 / Perkins Engine)
- - MF 7465/7475/7480 TRACTOR

- - MF 7475 TRACTOR (TIER 3 Sisu Engine)
- - MF 7475 TRACTOR (TIER 3 / Perkins Engine)
- - MF 7480 TRACTOR (TIER 3 / Perkins Engine)
- - MF 7480 TRACTOR (TIER 3 Sisu Engine)
- - MF 7485 TRACTOR (DYNA VT DYNA STEP / TIER 3)
- - MF 7485 / 7490 TRACTORS
- - MF 7490 TRACTOR (DYNA VT DYNA STEP / TIER 3)
- - MF 7495 TRACTOR
- - MF 7495 TRACTOR (DYNA VT DYNA STEP / TIER 3)
- - MF 7497 TRACTOR (TIER 3)
- - MF 7499 TRACTOR (TIER 3)
- - MF 7614 TRACTOR (DYNA 4)
- - MF 7615 TRACTOR (DYNA 4)
- - MF 7615 TRACTOR (DYNA 6)
- - MF 7615 TRACTOR (DYNA VT / DYNA STEP)
- - MF 7616 TRACTOR (DYNA 6)
- - MF 7616 TRACTOR (DYNA VT / DYNA STEP)
- - MF 7618 TRACTOR (DYNA 6)
- - MF 7618 TRACTOR (DYNA VT / DYNA STEP)
- - MF 7619 TRACTOR (DYNA 6)
- - MF 7619 TRACTOR (DYNA VT / DYNA STEP)
- - MF 7620 TRACTOR (DYNA 6)
- - MF 7620 TRACTOR (DYNA VT / DYNA STEP)
- - MF 7622 TRACTOR (DYNA 6)
- - MF 7622 TRACTOR (DYNA VT / DYNA STEP)
- - MF 7624 TRACTOR (DYNA 6)
- - MF 7624 TRACTOR (DYNA VT / DYNA STEP)
- - MF 7626 TRACTOR (DYNA 6)

- - MF 8110 TRACTOR
- - MF 8120 TRACTOR
- - MF 8130 TRACTOR
- - MF 8140 TRACTOR

- - MF 8210/8220 TRACTOR
- - MF 8240 TRACTOR

- - MF 8250 TRACTOR

- - MF 8260 TRACTOR LST |=> 01/2001
- - MF 8270/8280 TRACTOR
- - MF 8450 / 8460 TRACTORS (TIER 3) - |---> P341051 / |---> P325039 (e
- - MF 8450/8460 TRACTOR
- - MF 8470 / 8480 TRACTORS (TIER 3) - |---> P340017 / |---> P340054
- - MF 8470/8480 TRACTOR
- - MF 8650 TRACTOR (TIER 3 / 84 CTA Engine)
- - MF 8650 - Stage 3B - TRACTOR (TIER 4 / 84 AWI Engine)
- - MF 8660 TRACTOR (TIER 3 / 84 CTA Engine)
- - MF 8660 - Stage 3B - TRACTOR (TIER 4 / 84 AWI Engine)
- - MF 8670 TRACTOR (TIER 2-3 / 84 CTA Engine)
- - MF 8670 - Stage 3B - TRACTOR (TIER 4 / 84 AWI Engine - TIER 2 / 84
- - MF 8680 TRACTOR (TIER 3 / 84 CTA Engine)
- - MF 8680 - Stage 3B - TRACTOR (TIER 4 / 84 AWI Engine)
- - MF 8690 TRACTOR (TIER 2-3 / 84 CTA Engine)
- - MF 8690 - Stage 3B - TRACTOR (TIER 4 / 84 AWI Engine - TIER 2 / 84